

Westbase.io RealWear Staging Services



Our staging services provide configuration support, so your customer's Navigators or HMTs are ready to use out of the box. Separated into Basic and Advanced options, you can easily scope and select the activities you need.

Basic Staging

- | Upload of customer files to Navigators or HMTs, such as technical diagrams, instructional videos and maps.
- | Pre-configuration of Wi-Fi credentials for immediate connectivity at the customer site.
- | Import-ready file of device details to feed into the customer's EMM/MDM systems.

Advanced Staging

- | Basic staging, plus:
- | Foresight account creation and device association.
- | Application installation via Foresight.
- | Accessories setup (incl. LTE) for use with the Navigators or HMTs.

Additional Staging Services

- | Drop-shipping direct to the customer site.
- | Bespoke staging services are also available if you have any requirements not included in our basic and advanced options. Please contact your account manager to discuss.

LeadTimes & Pricing

Lead times: Our RealWear experts will work with you to understand your requirements and set a lead time to suit.

Pricing: Please contact your account manager for staging pricing. Bespoke pricing is available on a per-project basis.

For more information, or to order your staging services, simply contact Westbase.io:

hello@westbase.io

+44 (0) 1291 437 567 or

+31 (0) 35 799 2290

